



MONITORING AND CONTROL SOLUTIONS

Installing the Glycol Thermal Buffer

STEP 1:

Insert the temperature probe into the compression gland



STEP 2:

Remove the black cap from the glycol bottle and insert the probe into the bottle.

Tighten the white cap, as well as the compression gland

