



MONITORING AND CONTROL SOLUTIONS

Installing temperature sensors in Minus40 Fridges and Freezers

STEP 1:

Insert the temperature probe through the Temperature Sensor grommet on the side
(Remove the plug on both sides if required)



STEP 2:

Insert the temperature probe into the compression gland



STEP 3:

Remove the black cap from the glycol bottle and insert the probe into the Bottle.

Tighten the white cap, as well as the compression gland



STEP 4:

Place the bottle on a rack in the fridge (or just let it hang inside the freezer)



STEP 5:

Secure the logger on the side or back of the fridge or freezer using double-sided tape

